# EXP:5 Multi-Object Tracking Using CSRT Tracker

### Aim:

To track multiple objects in a video using OpenCV's MultiTracker with CSRT tracking algorithm.

## **Procedure:**

#### 1. Load the Video File:

- Open a video file using cv2.VideoCapture().
- o Read the first frame to initialize the tracking system.

#### 2. Prepare the Frame:

• Check if the frame is grayscale, and if so, convert it to BGR color format.

#### 3. Initialize Multi-Object Tracker:

- Use the CSRT tracker (cv2.legacy.TrackerCSRT\_create).
- Create a MultiTracker instance to handle multiple object tracking.

#### 4. Select Objects to Track:

- Manually select Regions of Interest (ROIs) from the first frame.
- Each selection can be confirmed by ENTER or SPACE, and the selection process can be ended by pressing 'q'.
- Assign random colors for each tracked object for visualization.

#### 5. Add Selected ROIs to MultiTracker:

 Add the manually selected bounding boxes to the MultiTracker along with individual tracker instances.

#### 6. Start Tracking Across Frames:

- Read frames sequentially from the video.
- Update all trackers and retrieve the updated bounding box positions.
- Draw rectangles and labels (e.g., Object 1, Object 2, etc.) around the tracked objects.
- Show the output video frame-by-frame in a window.

#### 7. Exit Condition:

o Press 'q' at any time during video playback to stop tracking and exit the program.

## Code:

```
import cv2
import numpy as np

# Load video

cap = cv2.VideoCapture("/content/29917-383980366_small.mp4")
if not cap.isOpened():
    print("Error: Could not open video.")
    exit()

# Read first frame
```

```
ret, frame = cap.read()
if not ret:
    print("Error: Failed to read the first frame.")
    exit()
print("Frame shape:", frame.shape)
print("Frame dtype:", frame.dtype)
# Convert grayscale to BGR if needed
if len(frame.shape) == 2:
    frame = cv2.cvtColor(frame, cv2.COLOR_GRAY2BGR)
# Initialize MultiTracker with CSRT
tracker = cv2.legacy.TrackerCSRT_create
multiTracker = cv2.legacy.MultiTracker_create()
# Select objects to track
print("Select the objects to track and press ENTER or SPACE. Press Q
to start tracking.")
bboxes = []
colors = []
while True:
```

```
bbox = cv2.selectROI('MultiTracker', frame, fromCenter=False,
showCrosshair=True)
    bboxes.append(bbox)
    colors.append((np.random.randint(0, 255), np.random.randint(0,
255), np.random.randint(0, 255)))
    print("Press 'q' to quit selecting boxes and start tracking.")
    print("Press any other key to select another object.")
    k = cv2.waitKey(0) & 0xFF
    if k == ord('q'):
       break
cv2.destroyAllWindows()
# Add selected boxes to MultiTracker
for bbox in bboxes:
    print("Adding tracker for bbox:", bbox)
    multiTracker.add(tracker(), frame, bbox)
# Tracking loop
while cap.isOpened():
    ret, frame = cap.read()
```

```
print("End of video or failed to read frame.")
        break
    if len(frame.shape) == 2:
        frame = cv2.cvtColor(frame, cv2.COLOR_GRAY2BGR)
    success, boxes = multiTracker.update(frame)
    for i, newbox in enumerate(boxes):
        p1 = (int(newbox[0]), int(newbox[1]))
        p2 = (int(newbox[0] + newbox[2]), int(newbox[1] + newbox[3]))
        cv2.rectangle(frame, p1, p2, colors[i], 2, 1)
        cv2.putText(frame, f"Object {i+1}", (p1[0], p1[1] - 10),
cv2.FONT_HERSHEY_SIMPLEX, 0.6, colors[i], 2)
    cv2.imshow('MultiTracker', frame)
    if cv2.waitKey(30) \& 0xFF == ord('q'):
        break
cap.release()
cv2.destroyAllWindows()
```

if not ret:

# **Output:**



# Result:

Successfully implemented a multi-object tracking system using CSRT trackers with manual ROI selection. The system accurately tracks the selected objects through the video.